


AIR BELT SANDER

(20*520mm)



No.	Part No.	Description	Q'ty	No.	Part No.	Description	Q'ty
1	707F001	Throttle Lever	1	35	707F035	Driver Pulley	1
2	707F002	Lever Pin	1	36	707F036	Dust Cover	1
3A	707F003A	Motor Housing	1	37	707F037	Cover Latch	1
4A	707F004A	O-Ring	1	38	707F038	Cap Screw	2
5A	707F005A	Valve Stem	1	39	707F039	Tension Bar	1
6A	707F006A	O-Ring	1	40	707F040	Lever Pin	1
8A	707F008A	Air Controller	1	41	707F041	Spring	1
12	707F012	Lock Nut	1	42	707F042	Lever Pin	1
13	707F013	O-Ring	1	43	707F043	Screw	1
14	707F014	Housing	1	44	707F044	Washer	1
15	707F015	Ball Bearing	1	45	707F045	Tension Spring	1
16	707F016	Front End Plate	1	46	707F046	Tension Arm	1
17	707F017	Spacer	1	47	707F047	Idle Pulley	1
18	707F018	Rotor	1	48	707F048	Collar	1
19	707F019	Sunk Key	1	49	707F049	Ball Bearing	2
20	707F020	Rotor Blade	5	50	707F050	Screw	1
21	707F021	Cylinder	1	51	707F051	Screw	1
22	707F022	Rear Plate	1	52	707F052	Lock Nut	1
23	707F023	Ball Bearing	1	53	707F053	Shoe	1
24	707F024	O-Ring	1	54	707F054	Screw	1
25	707F025	Motor Nut	1	55A	707F055A	Sliencer	1
26	707F026	Set Screw	2	56A	707F056A	O-Ring	1
27	707F027	Finger Plate	1	57A	707F057A	Air Deflector	1
28	707F028	Wheel Cover Lid	1	58A	707F058A	Air Inlet	1
29	707F029	Wheel Cover Incl. Spacer	1	59	707F059	Grinding Belt	1
30	707F030	Roll Pin	1	60	707F060	Seal	1
31	707F031	Lock Pin	1	61	707F061	Valve Stem	1
32	707F032	Set Screw	1	62	707F062	Spring	1
33	707F033	Lock Nut	1	63	707F063	O-Ring	1
34	707F034	Washer	1	64	707F064	Snap Ring	1